



LAT Flight Software

LMC Manual

Type: User Manual
Version: V0-0-1
Author: S.Maldonado
Created: 4 February 2005
Updated: 28 February 2007
Printed: 7 March 2007

Manual for the LAT multiplexed counters package.

Contents

0	Introduction	1
0.0	Overview	1
0.1	Reference Documentation	1
1	Package Description	2
1.0	Shareables	2
1.1	Executables	2
1.2	Utilities	2
2	Implementation	3
2.0	Task Architecture	3
2.0.0	Execution	3
2.1	Control Structures	3
2.2	Counter Data	3
2.2.0	CAL LRS Counter Data	4
2.2.1	TKR LRS Counter Data	4
2.2.2	ACD Tile Counter Data	4
2.2.3	TEM Deadtime Counter Data	4
3	Programming	5
3.0	Initialization	5
3.1	Application Control	5
4	Command and Telemetry	6
4.0	Telecommands	6
4.0.0	LMCCALLRS	6
4.0.1	LMCTKRLRS	7
4.0.2	LMCACDTILEPAIR	7
4.0.3	LMCACDTILEALL	7
4.0.4	LMCTEMDEADTIME	8
4.0.5	LMCSTOPCOUNT	8
4.0.6	LMCNOOP	9
4.1	Telemetry	9
4.1.0	Packet Descriptions	9
4.1.1	CAL LRS Telemetry	9
4.1.2	TKR LRS Telemetry	9
4.1.3	ACD LRS Telemetry	10
4.1.4	TEM LRS Telemetry	10

0 Introduction

The LMC package implements access to the low-rate multiplexed science counters for the CAL, TKR, and ACD hardware.

0.0 Overview

Each TEM maintains registers for counting of the CAL trigger primitives, TKR 3-in-a-row signals, and the deadtime. Each counter is multiplexed by setting its corresponding counter mask register. ACD tile counters are accessed through the GEM. The GEM maintains three registers that collectively multiplex and count the number of times a signal is present in any two of the ACD's 108 tiles. One register selects which tile pair to count, and the two remaining registers contain the corresponding counter values.

Because all counter registers are saturating, they will stop counting once the maximum value is reached. In order to prevent saturation, the counters are reset after each sample interval. The resulting values reflect counts for a single specified interval.

0.1 Reference Documentation

1. LAT-TD-00605, "Tower Electronics Module - Programming ICD specification", by Michael Huffer
2. LAT-TD-01545, "GLT Electronics Module - Programming ICD specification", by Michael Huffer

1 Package Description

This section describes the CMX package layout for LMC.

1.0 Shareables

- liblmc - The main LMC library

1.1 Executables

- N/A

1.2 Utilities

- N/A

2 Implementation

This section provides an overview of the LMC software implementation.

2.0 Task Architecture

LMC is implemented as an ITC delegated task. The task performs the following primary functions:

- Receive, validate, and process telecommand packets
- Construct and submit LCB command lists
- Validate and process LCB result lists
- Packetize counter data and telemeter using the science data interface

2.0.0 Execution

LMC utilizes wake-up timers (WUT) provided by the PBS package to allow for simultaneous fixed interval sampling of each counter. Each LCB result list callback strobos the WUT at parameterized intervals. This results in the resubmission of the LCB command list, which continues until the specified sample limit has been reached, or until the stop command is received.

2.1 Control Structures

For each counter type, TEM, CAL, TKR, and ACD, a separate control block is maintained. Each control block contains a WUT, LCB command and result lists, and packet data buffers.

2.2 Counter Data

The counter data reported for each subsystem is described in the following sections. Each sample generally contains the raw counter data read from the registers, a delta timestamp covering the duration of the sample, and a data mask describing what components were included in the sample.

Because all counter registers are saturating, they will stop counting once the maximum value is reached. In order to prevent saturation, the counters are reset after each sample interval. The resulting values reflect counts for a single specified interval.

2.2.0 CAL LRS Counter Data

These registers count CAL specific trigger primitives in the low and high energy ranges. CAL low-rate science data consists of two 16 bit counters and a 32 bit time delta specified in LCB clock tics. The masks specified in the telecommand are reported back with the counter data.

see [1] section 2.3.3.3 for specifics on interpreting the CAL counter data

2.2.1 TKR LRS Counter Data

These register count TKR specific trigger primitives for 3-in-a-row signals. TKR low-rate science data consists of four 16 bit counters and a 32 bit time delta specified in LCB clock tics. The masks specified in the telecommand are reported back with the counter data

see [1] section 2.3.4.4 for specifics on interpreting the TKR counter data

2.2.2 ACD Tile Counter Data

These registers count the number of times a signal was present in any of the ACD's 108 tiles. ACD tile counter data consists of two 16 bit counters for each tile pair, and a 32 bit time delta specified in LCB clock tics. The tile numbers are also included in the reported data.

see [2] section 2.6.2 for specifics on interpreting the ACD tile counter data

2.2.3 TEM Deadtime Counter Data

These registers count the deadtime incurred in the TEM by CAL and TKR trigger primitives. TEM deadtime counter data consists of a 32 bit counter for each of the 16 TEMs, and a 32 bit time delta specified in LCB clock tics. The TEM enable mask is also included in the reported data.

see [1] section 2.3.5 for specifics on interpreting the TEM deadtime counter data

3 Programming

The LMC package provides several public control interfaces that are used to initialize, start, and stop the LMC system.

3.0 Initialization

The LMC initialization call takes no parameters.

`LMC_initialize()`

3.1 Application Control

`LMC_start()` - starts the LMC task

`LMC_shutdown()` - releases all LMC memory resources

4 Command and Telemetry

This section covers the command and telemetry interfaces of the LMC package.

4.0 Telecommands

The LMC package system supports the following telecommands:

Command	APID	Function Code	Description
LMCCALLRS	0x69c	0	Initiates collection of CAL low-rate science data
LMCTKRLRS	0x69c	1	Initiates collection of TKR low-rate science data
LMCACDTILEAPAIR	0x69c	2	Initiates collection of a pair of ACD tile counter data
LMCACDTILEALL	0x69c	3	Initiates collection of all ACD tile counter data
LMCSTOPCOUNT	0x69c	4	Terminates active counter operations
LMCTEMDEADTIME	0x69c	5	Initiates collection of TEM deadtime low-rate science data
LMCNOOP	0x69c	4	No Operation

4.0.0 LMCCALLRS

This command initiates sampling of CAL low-rate science counters at the specified rate, for the enabled TEMs. Each sample generates one telemetry packet.

Parameter	Description
LMCINTERVAL	time between counter samples, minimum of 100 milliseconds, maximum of 4000 milliseconds

Parameter	Description
LMCCOUNT	number of counter samples to perform
LMCCALMASK	32 bit low-rate science multiplex mask
LMCTEMMASK	16 bit enable word specifying which TEMs to sample

see [1] section 2.3.3.2 for specifics on setting the CAL mask

4.0.1 LMCTKRLRS

This command initiates sampling of CAL low-rate science counters at the specified rate, for the enabled TEMs.

Parameter	Description
LMCINTERVAL	time between counter samples, minimum of 100 milliseconds, maximum of 4000 milliseconds
LMCCOUNT	number of counter samples to perform
LMCTKRMASK	32 bit low-rate science multiplex mask
LMCTEMMASK	16 bit enable word specifying which TEMs to sample

see [1] section 2.3.4.3 for specifics on setting the TKR mask

4.0.2 LMCACDTILEPAIR

This command initiates sampling of ACD tile counters at the specified rate, for the specified tile pair. Each sample generates one telemetry packet containing counter values for both tiles. Note that tile *pair* and tile *all* counter operations are mutually exclusive.

Parameter	Description
LMCINTERVAL	time between counter samples, minimum of 100 milliseconds, maximum of 4000 milliseconds
LMCCOUNT	number of counter samples to perform
LMCTILEID0	ACD tile number
LMCTILEID1	ACD tile number

see [2] section 2.6.2 for specifics on setting the ACD tile numbers

4.0.3 LMCACDTILEALL

This command initiates sampling of all ACD tile counters at the specified rate. Each sample generates two telemetry packets. Note that tile *pair* and tile *all* counter operations are mutually exclusive.

Parameter	Description
LMCINTERVAL	time between counter samples, minimum of 100 milliseconds, maximum of 4000 milliseconds
LMCCOUNT	number of counter samples to perform

4.0.4 LMCTEMDEADTIME

This command initiates sampling of TEM deadtime counters at the specified rate. Each sample generates one telemetry packet.

Parameter	Description
LMCINTERVAL	time between counter samples, minimum of 100 milliseconds, maximum of 4000 milliseconds
LMCCOUNT	number of counter samples to perform
LMCTKRDSAB	Bit to disable counting of TKR contributed deadtime
LMCCALDSAB	Bit to disable counting of CAL contributed deadtime
LMCTOTALDSAB	Bit to disable counting of the CAL and TKR deadtime sums
LMCTEMMASK	16 bit enable word specifying which TEMs to sample

see [1] section 2.3.5 for specifics on setting the TEM deadtime masks

4.0.5 LMCSTOPCOUNT

This command stops the specified counter operation.

Parameter	Description
LMCCOUNTOPCODE	Opcode of counter operation to terminate

Opcode	Description
0	All active counters
1	CAL low-rate science counter
2	TKR low-rate science counter
3	ACD tile pair counters
4	ACD tile all counters
5	TEM deadtime low-rate science counter

4.0.6 LMCNOOP

This command takes no parameters and if received will elicit a success response. The purpose of this command is to verify task communications without taking any action.

4.1 Telemetry

This section describes the telemetry interface for the LMC package. LMC packets are self-describing and fixed length. The content/format is determined by the multiplex setting specified in the initiating telecommand. For detailed descriptions of the packet layouts, refer to the LAT Telecommand and Telemetry document.

4.1.0 Packet Descriptions

Name	APID	Description
cal_cnt	0x2c3	CAL Low Rate Science Counters
tkr_cnt	0x2c4	TKR Low Rate Science Counters
acd_cnt	0x2c5	ACD Tile Low Rate Science Counters
dead_cnt	0x2c6	TEM Deadtime Low Rate Science Counters

4.1.1 CAL LRS Telemetry

Mnemonic	Description
LMCTEMENABLE	The TEM enable mask as contained in the initiating telecommand
LMCCALLRSMASK	The CAL enable mask as contained in the initiating telecommand
LMCCALTEM[X]DT	Elapsed time in LCB clock tics of the sample duration for TEM X, where X=0-15
LMCCALTEM[X]CNT0	The raw CAL counter 0 data for TEM X, X=0-15
LMCCALTEM[X]CNT1	The raw CAL counter 1 data for TEM X, X=0-15

4.1.2 TKR LRS Telemetry

Mnemonic	Description
LMCTEMENABLE	The TEM enable mask as contained in the initiating telecommand
LMCTKRLRSMASK	The CAL enable mask as contained in the initiating telecommand
LMCTKRTEM[X]CNT[Y]D	Elapsed time in LCB clock tics of the sample duration for TEM X counter Y,

Mnemonic	Description
	where X=0-15, Y=0-1
LMCTKRTEM[X]CNT[Y]U	The raw TKR upper counter Y data for TEM X, X=0-15, Y=0-1
LMCTKRTEM[X]CNT[Y]L	The raw TKR lower counter Y data for TEM X, X=0-15, Y=0-1

4.1.3 ACD LRS Telemetry

Mnemonic	Description
LMCACDCNT[X]T[Y]ID	ACD Tile ID, where X=0-26 (counter index) , Y=0-107 (tile ID)
LMCACDCNT[X]DT	Elapsed time in LCB clock tics of the sample duration for counter index X, where X=0-26 (counter index)
LMCACDCNT[X]T[Y]VAL	The raw ACD tile counter data, where X=0-26 (counter index) , Y=0-107 (tile ID)

4.1.4 TEM LRS Telemetry

Mnemonic	Description
LMCTEMENABLE	The TEM enable mask as contained in the initiating telecommand
LMCTEMDEADMASK	The TEM deadtime enable mask as contained in the initiating telecommand
LMCDEADTEM[X]DT	Elapsed time in LCB clock tics of the sample duration for TEM X, where X=0-15
LMCDEADTEM[X]CNT	The raw deadtime counter for TEM X, where X=0-15